

STE-06 UNDER CURRENT ALARM 1-PHASE CIRCULATION PUMP, COOLING

An under current relay is connected and measures the current to the circulation pump. If the current falls below 200 mA during normal operation or if the pump is manually switched off during operation, a pump alarm is triggered.

The switches on the relay are set as shown in the picture below.

