

STE-04 VALVE AND ACTUATOR WATER COOLING

Together with STE-03 this code specifies the valve and actuator to be used.

The code should be entered in the following format:

For example: **STE-04-2V-15-0040**

STE-04 tells you it is a code for water cooling.

-2V tells you it is a 2-way valve (can also be 3V for 3-way valve).

-15 tells you the pipe diameter (in this case DN 15).

-0040 is the KVS-value (0,4) for the valve actuator.