

## STH-S1M-... CONTROL OF DAMPER WITH FIRE PROTECTION FUNCTION

If, when and how often the the dampers are to be tested can be set in Climatix. If the fan does not work properly during a test, an alarm is triggered and the unit is stopped.

Choose between:

STH-S1M-00	No auto testing of fire dampers, one group, up to 4 dampers (Max 40VA)
STH-S1M-10	Auto testing of fire dampers, one group, up to 4 dampers (Max 40VA)
STH-S1M-20	No auto testing of fire dampers, two groups, up to 8 dampers (Max 2x40VA)
STH-S1M-30	Auto testing of fire dampers, two groups, up to 8 dampers (Max 2x40VA)