STH-F1B-… EXTERN FIRE-FAN CONTROL

Climatix can be configured to control a combustion gas fan, with or without pressure switch monitoring. The pressure switch is used to check whether the fire fan is working properly during auto tests.

When and how often the fan is to be tested can be set in Climatix. If the fan does not work properly during a test, an alarm is triggered and the unit is stopped.

Choose between:

STH-F1B-00	no pressure switch monitoring.
STH-F1B-10	with pressure switch monitoring.